

Tea Cosy

Pattern & Instructions



Contents


Pattern Piece
Instructions

You will need:

Printer *Print at 100% on A4
Your finished embroidered panel
Back Panel fabric (30x42cm/12x16In)
*30x50cm/12x20In inc. in main kit
Lining Fabric (60x42cm/24x16In)
Wadding (60x42cm/24x16In)
Bias Binding (6x120cm)
Sewing needle, Sewing thread
Sewing machine (optional)



Instructions

Note: All Seam Allowances are 1.5cm / 0.59Inches. The fabrics do not have a right/wrong side, “right and wrong side” are used for construction purposes. You can stitch by hand or machine.



1. Cut out your embroidered & plain back panel. Cut your bias binding (6cm/2.36 inches wide) - create a hanging loop by folding the bias binding in half (lengthways) stitch (lengthways) with a 1-1.5cm SA - approx 10cm long and pull rightside out - press flat.


Place these right sides together (place your top loop and label in the seam between these 2 panels) stitch together. Press the seam open, and turn right side out.



2. Cut your 1 pair of lining, Place the lining panels right sides together and stitch, then press the seams open and keep as wrong side out.



3. Cut 1 pair of wadding. Place the edge of each wadding next to each other and zig zag stitch.



4. Place the stitched wadding inside the embroidered layer, place the lining inside the wadding layer. optional: pin the sides and centres together at the open base.

5. Attach the bias binding to the right side of the embroidered layer along the raw hem edge. Stitch in place 1.5cm up from the raw edge.

6. Fold down and press, then turn to the inside and fold again. Hand stitch the folded edge to the lining.



1.5cm / 0.59 inches SA

Bias Strip:
6cm / 2.36 Inches Wide,
120cm / 48Inch Length

F
O
L
D



C
E
N
T
R
E

L
I
N
E

Tea Cosy
CUT 1 Pair Outer/Self
CUT 1 Pair Lining
CUT 1 Pair Wadding

Outer Self & Lining Cut Line

Wadding Cut Line



1 Inch



1 cm